


Zusatz - Produktinformation

Linearantrieb, Typ EA-L synchronisiert


Synchronisation von 1, 2, 3 oder 4 Linearantrieben in Verbindung mit der Stürmann -Gleichlaufregelung, Typ GE 73*.

Elektrischer Anschluss



Achtung: Motorkabel (Klemmen 1 bis 5 = elektronische Lastabschaltung/Geber und Gleichlaufregelung, Typ GE 73*) unbedingt richtig anschließen. Andernfalls wird der Geber im Antrieb und/oder die Gleichlaufregelung zerstört!

Achtung: Elektrischen Anschluss nicht erden. Der Antrieb darf nur mit 24 V Schutzkleinspannung betrieben werden. "F" nicht erden, nicht durchschleifen!




Zusatz - Produktinformation

Linearantrieb, Typ EA-L synchronisiert


Synchronisation von 1, 2, 3 oder 4 Linearantrieben in Verbindung mit der Stürmann -Gleichlaufregelung, Typ GE 73*.

Elektrischer Anschluss



Achtung: Motorkabel (Klemmen 1 bis 5 = elektronische Lastabschaltung/Geber und Gleichlaufregelung, Typ GE 73*) unbedingt richtig anschließen. Andernfalls wird der Geber im Antrieb und/oder die Gleichlaufregelung zerstört!


Achtung: Elektrischen Anschluss nicht erden. Der Antrieb darf nur mit 24 V Schutzkleinspannung betrieben werden. "F" nicht erden, nicht durchschleifen!



Product Information


Spindle actuator Typ EA-L ****/****

Synchronisation of 1, 2, 3 or 4 spindle actuator in connecting with Synchronizer, type GE 73* Stürmann Systeme.



Attention: Connect the actuator cable exactly (Terminal 1 until 5 = electronic load cut off / trigger and synchronizer, type GE 73*). Otherwise the trigger in the actuator and / or the synchronizer will be destroyed!

Attention: Do not earth electrical connection. Please take notice of actuator voltage is 24 V DC!




① Fixing notch for surface housing.

Date: s-ea-l-z2.cdr

Product Information


Spindle actuator Typ EA-L ****/****

Synchronisation of 1, 2, 3 or 4 spindle actuator in connecting with Synchronizer, type GE 73* Stürmann Systeme.



Attention: Connect the actuator cable exactly (Terminal 1 until 5 = electronic load cut off / trigger and synchronizer, type GE 73*). Otherwise the trigger in the actuator and / or the synchronizer will be destroyed!

Attention: Do not earth electrical connection. Please take notice of actuator voltage is 24 V DC!



① Fixing notch for surface housing.

Date: s-ea-l-z2.cdr